

DIP-переключатели для настройки номера субмодуля CTV IP

Номер субмодуля	DIP1	DIP2	DIP3	DIP4	DIP5	DIP6	DIP7	DIP8*
1	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF
2	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF
3	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF
4	OFF	OFF	ON	OFF	OFF	OFF	OFF	OFF
5	ON	OFF	ON	OFF	OFF	OFF	OFF	OFF
6	OFF	ON	ON	OFF	OFF	OFF	OFF	OFF
7	ON	ON	ON	OFF	OFF	OFF	OFF	OFF
8	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF

* Должен быть в позиции ON только, если ваш субмодуль - последний или единственный в цепочке субмодулей